

solar road stud

IPL-SRS

1. Drill a hole

2. Clean the hole

3. Fill hole with adhesive bond

Do not fill completely, leave 20mm of space on the top part

